






# Revive Double Hung Sample Loose Components Installation Instructions

## Verify the following prior to beginning

- Kit contains all material listed
- Wood species/finish is correct
- Head stop/Sill stop length = frame width
- Side stop length = frame height + 4 21/32"
- Velcro is attached to stops  
(2x head stop, 3x side stops, 3x sill stop)

If any of the items in the above list are incorrect, contact an inside sales representative.

## Stop & Velcro Kit Contents

- 1x – Inside Sill Stop (2 Velcro Attached) 
- 1x – Head Inside Stop (2 Velcro Attached) 
- 2x – Side Inside Stops (3 Velcro Attached) 
- 10x – 3 1/2" Velcro Strips (P/N: 9821) Attached To Stops

### STEP 1

Remove stops from kitted bag

### STEP 2

Apply head stop to the head of the sample frame, matching up Velcro.

### STEP 3

Apply side stops to the interior jamb of the sample frame, matching up Velcro

### STEP 4

Apply sill stop to the interior sill, matching up Velcro

